



Barnhardt Manufacturing Company  
 dba *NCFI Polyurethanes*  
 PO Box 1528 • Mount Airy, NC 27030  
 800-346-8229 www.NCFI.com

## 11-037 INSULBLOC® SMARTSPF TECHNICAL DATA

### DESCRIPTION:

11-037 InsulBloc® SmartSPF is a two component, self-adhering, seamless, closed cell, spray applied polyurethane foam insulation system. This system has been formulated with highly insulating HFO as the blowing agent. The InsulBloc® SmartSPF insulation system is suitable for application on the exterior or interior side of Type I, II, III, IV, & V building walls as well as other insulation applications.

### DISTINGUISHING CHARACTERISTICS:

- Low GWP
- High R-Value
- High Yields
- Air Impermeable Insulation at 1/2"
- Class II Moisture Vapor Retarder @1.3"
- Meets ASTM E-84, FS <25, SD <450 @ 4"
- FEMA Flood Resistance - Class 5
- Water Resistive Barrier (AC71) @ 1"
- Low VOC per CDPH Standard V 1.2, 2017

R-Values*	
Thickness (inches)	R-Value (°F-hr-ft <sup>2</sup> / Btu)
1	7.1
2	14
3	20
3.5	23
5.5	37
6	40
7	47
8	53
9	60

\*Note: As with all insulating materials, the R-value will vary with age and use conditions.

For proper use of this NCFI insulating material refer to the NCFI Application Information and any of the following codes or guides:

- 2018 International Building Code Chapter 26 or Residential Code Section R316 & R806

### TYPICAL PHYSICAL PROPERTIES<sup>1</sup>:

Free Rise Core Density <sup>2</sup> ASTM D 1622	2 pcf
Closed Cell Content ASTM D 6226	>90%
R-value @ 1" ASTM C 518	7.1
Air Perm @1/2" & 75 Pa ASTM E2178	≤ 0.02 perms
Moisture Vapor Perm ASTM E96 @ 1"	1.3 perms
Compressive Strength ASTM D1621	27 psi
Tensile ASTM D1621	45 psi
Flammability ASTM E-84 @ 4 inches	Flame Spread ≤25 Smoke Dev ≤450
Max Service Temperature	180°F

<sup>1</sup>The above values are average values obtained from laboratory experiments and should serve only as guide lines.

<sup>2</sup>Free rise core density should not be confused with overall density. Overall densities are always higher than free rise core densities and take into account skin formation, thickness of application, environmental conditions, etc.

- IAPMO Evaluation Report 667
- IAMPO Evaluation Report 0340
- API Fire Safety Guidelines for Use of Rigid Polyurethane and Polyisocyanurate Foam Insulation in Building Construction (AX230)
- Go to: [polyurethane.americanchemistry.com](http://polyurethane.americanchemistry.com) and find the "Products, Resources, and Documents Library" tab

Polyurethane products manufactured or produced from this liquid system may present a serious fire hazard if improperly used or allowed to remain exposed or unprotected. The character and magnitude of any such hazard will depend on a broad range of factors, which are controlled and influenced by the manufacturing and production process, by the mode of application or installation and by the function and usage of the particular product. **Any flammability rating contained in this literature is not intended to reflect hazards presented by this or any other material under actual fire conditions. These ratings are used solely to measure and describe the product's response to heat and flame under controlled laboratory conditions.** Each person, firm or corporation engaged in the manufacture, production, application, installation or use of any polyurethane product should carefully determine whether there is a potential fire hazard associated with such product in a specific usage,



## 11-037 Application Information

### STORAGE OF 11-037 CHEMICALS:

Avoid storage in freezing temperatures. Storing chemicals above 90°F should be avoided as much as possible. Do not store in direct sunlight. The shelf life of unopened A2-000 is 24 months and the B11-037 is 6 months.

**SPRAYING 11-037 CHEMICALS:** Chemicals should be between 65°F and 85°F for proper processing through the spray equipment. Chemicals shipped during winter or summer months may need extra time to stabilize back into the 65°F to 85°F range. Excessively warm chemicals should be cooled prior to opening the drums for safety and processing reasons. Cold chemicals can cause poor mixing, pump cavitation or other processing problems. Keep drums tightly closed when not in use and under dry air or nitrogen pressure of 2-3 psi after they have been opened.

### SAFE HANDLING OF LIQUID COMPONENTS:

Use caution in removing bungs from the container. Loosen the small bung first to allow any built-up vapor pressure to stabilize before completely removing. **B component will froth at elevated temperatures.** Avoid prolonged breathing of vapors. In case of chemical contact with eyes, flush with water for at least 15 minutes and get medical attention. For further information go to [www.spraypolyurethane.org](http://www.spraypolyurethane.org) and click on the Resources tab in the Professional Contractors section.

### APPLICATION GUIDELINES:

11-037 is suitable for application to most construction materials including wood, masonry, concrete, and metal. Application can be to the exterior or interior side of wall surfaces. 11-037 can be applied to surfaces that will be in contact with soil and intermittent contact with water, such as below grade exterior foundation and basement walls or under concrete slab floors. To ensure proper adhesion, all substrate surfaces should be dry, clean of dust or flaking surface, loose scale, ice or frost. All metal surfaces must be free of oil, grease, etc. Uncoated metals may require a primer coat.

No flammable chemicals, such as wasp and hornet sprays, should be sprayed in the area of the foam application 24 hours before the

application. No such chemical can be sprayed after the foam application until the foam has cooled to room temperature.

### APPLICATION AROUND PLASTIC PIPES:

Based on a series of extensive studies, the 11-037 system can be applied in contact with PVC, CPVC, ABS, PP-R and PEX plastic pipes. The pipes must not be pressurized during the foam application. The foam pass applied in contact with the pipe should not exceed 2" thickness in order to prevent excessive exothermic heat at the pipe to foam interface. Allow 2 minutes cooling between each additional foam pass. The total foam thickness is limited to that thickness permitted in that area of the building assembly.

### APPLICATION AROUND ELECTRICAL WIRES:

Based on NCFI testing, the 11-037 system can be applied in contact with electrical wires. Spray foam applicators must spray the foam in such a manner that the expanding foam does not stretch and distort the wires. Light gauge wires which will be encapsulated in the foam layer should have the foam installed behind the wires and allowed to cool prior to applying a top layer to cover the wire. Use a shallow lift of 3/4" of foam to cover the wire. Wait the required 2 minutes between passes when adding more foam thickness to achieve the desired R-value.

### APPLICATION PASS THICKNESS:

Spraying foam will generate heat. Foam which is applied too thick in single passes can build temperatures which will degrade cell structure and not produce foam with optimum properties. In the most extreme case, 11-037 could reach dangerously high temperatures inside the finished foam which could lead to splitting, charring, or even spontaneous combustion. The maximum pass thickness for 11-037 is 4 inches. When applying pass thicknesses greater than 2 inches, wait 10 minutes or until the foam surface has cooled to ambient temperature before adding additional foam passes. Multiple layers can be applied to achieve the desired R-value.

The information on our data sheets is to assist customers in determining whether our products are suitable for their applications. The customers must satisfy themselves as to the suitability for specific cases. NCFI warrants only that the material shall meet its specifications. This warranty is in lieu of all other written or unwritten, expressed or implied warranties, and NCFI expressly disclaims any warranty of merchantability, fitness for a particular purpose, or freedom from patent infringement. Accordingly, buyer assumes all risks whatsoever as to the use of the material. Buyer's exclusive remedy as to any breach of warranty, negligence or other claim shall be limited to the purchase price of the material. Failure to adhere to any recommended procedures shall relieve NCFI of all liability with respect to the material or the use thereof.





## 11-037 Application Information

**EQUIPMENT AND COMPONENT RATIOS:** The 11-037 system, consisting of the A2-000 and B11-037 components, is formulated for spraying with a two component pump specifically designed for spray polyurethane foam systems. The B drum is connected to the resin pumps and the A drum is connected to the isocyanate pumps. The proportioning pump ratio is 1 to 1. Dispensing temperature should be set at approximately 130°F to give a good pattern. Due to equipment variations, the application temperature settings may need to be adjusted to achieve a good spray pattern. For higher-pressure settings above 1,000 psi, the temperature settings can be slightly lower.

### OPTIMUM ADHESION TEMPERATURE OF SURFACE TO BE SPRAYED:

The surface should be between 10°F and 120°F when applying 11-037. In this range the warmer the surface, the better the adhesion. When surface temperatures fall below 60°F, adhesion may be aided by applying a thinner flash coat followed by a full thickness pass while the flash coat is still warm but no longer tacky to the touch. Another technique to improve adhesion in studwall assemblies is to apply a cant along the side of the studs before filling in the center of the stud bay.

11-037 Systems	Temperature Range Guideline
SLOW	70°F and up
REG	40°-80°F
FAST	10°-50°F

\*The above table are guidelines for optimal product performance  
Elevations above 4500ft : Order HA ( High Altitude) product line

### VAPOR BARRIER PROTECTION ON COLD STORAGE APPLICATIONS:

When InsulBloc®SmartSPF is used in structures subject to continuous cold temperatures, such as coolers and freezers, a Class I moisture vapor barrier (0.1 perm or less) is normally required on the “warm” side of the foam insulation. Contact NCFI for specific recommendations.

### CODE-COMPLIANT FIRE RESISTANCE:

Building Codes require foam plastic insulation, such as 11-037, be separated from the interior of the building by a 15 minute thermal barrier of ½” gypsum board or other approved material. Refer to IAMPO ER 667 for details. When Fire Resistive Wall Assemblies are required, contact NCFI Polyurethanes for specific alternate approvals for InsulBloc®SmartSPF.

### WEATHER PROTECTION OF FINISHED FOAM ON EXTERIOR APPLICATIONS:

The finished surface of sprayed polyurethane foam should be protected from adverse effects of ultraviolet rays of direct sunlight which can cause dusting and discoloration. Protective coatings designed for use with polyurethane foam are available. On exterior applications where a masonry veneer or mechanically attached covering is to be installed, the InsulBloc®SmartSPF foam surface may be exposed to UV light up to 6 months.

### ATTICS and CRAWL SPACES

11-037 has passed testing for application in limited access attics and crawl spaces without the code prescribed ignition barrier covering. The foam thickness can be up to 8” on wall cavities and 10” in ceiling cavities

### OTHER APPLICATION AND SAFETY CONSIDERATIONS:

Before 11-037 is to be applied, there are many safety and application situations to consider. All spray foam applicators must evaluate the job prior to beginning the spray foam application. It is impossible to anticipate every issue and provide explicit guidance in this product data sheet. If there is a question regarding some aspect of the planned application, consult with NCFI for more guidance. The NCFI Product Stewardship Manual contains additional information and should be reviewed often enough by all spray foam applicators to remain familiar with the contents. The American Chemistry Council (ACC), the Center for Polyurethanes Industry (CPI) and the Spray Polyurethane Foam Alliance (SPFA) also publish information regarding the safe handling and application of spray foam chemicals. If there are any questions regarding the application of the 11-037 system, contact an NCFI representative.

### VENTILATION OF SPRAY AREA:

Spraying foam will generate a mist and fumes with a distinct odor. For interior applications the building area must be vented with fresh air to dissipate the odor. The amount of air flow and time for venting will vary based on each situation. A closed attic area may require fans to force air into and out of the space. An open building that does not have the doors and windows installed may have sufficient air flow to vent the odor fairly quickly. Reentry time for closed-in areas being vented with fans is typically about 24 hours. Other workers should remain out of the immediate area during this venting

